



Cassette Mount

INSIDE MOUNT

Minimum Casement Depth: $1\frac{3}{8}$ "

Minimum Casement Depth,
Fully Recessed: $3\frac{5}{8}$ "

OUTSIDE MOUNT

Recommended Width Overlap
on Each Side: 3" (6" Total)

SHEER & LAYERED SHADES HEADRAIL DEPTH MOUNTING GUIDE

1. Place the appropriate headrail profile inside the window opening.
2. With guide in the window, check to see if the headrail has the minimum depth to mount. Indicators for fully recessing headrail in window casing/molding are also available to check.
3. Final depth may vary based on the thickness of valance fabric selected.

If product configuration is not found here, please reference the product information guide.

NOTE: When ordering a motorized shade, add $1\frac{1}{8}$ " to accommodate the battery pack.

SPRINGS WINDOW FASHIONS
The Best Experience Company 

20-0289-00 (03/21) 21-167800